1883608
Nautical Table

Parts and Hardware List

A.	Top	1 pc
B.	Post	1 pc
C.	Base	1 pc
D.	Allen Head Bolts	3 pcs
E.	Lock Washers	3 pcs
F.	Flat Washers	3 pcs
G.	Allen Head Wrench	1 pc

∗ Please make sure that you have all the parts indicated above before you begin assembly of this item.
∗ This item should be assembled on a soft surface to prevent scratching the finish during assembly.
∗ This item may require periodic tightening.

Hardware Illustrations



D. Allen Head Bolt



E. Lock Washer



F. Flat Washer

1883608
Nautical Table

Attach Post and Base

Parts required

A.	Top	1 pc	E.	Lock Washers	3 pcs
B.	Post	1 pc	F.	Flat Washers	3 pcs
C.	Base	1 pc	G.	Allen Head Wrench	1 pc
D.	Allen Head Bolts	3 pcs			

1. **Attach Post (B)** Place the Top (A) upside down on a soft surface. Insert the exposed threads of Post (B) into the pre-threaded holes of Top (A), tighten by turning in a clockwise direction. See illustration.
2. **Attach Base (C) .** Align the pre-drilled holes in the Base (C) with the pre-threaded holes in the Post (B). Secure with Allen Head Bolts (D), Lock Washers (E), Flat Washers (F) by using Allen Head Wrench (G).See illustration.



Illustration